Skip to main content Skip to primary navigation	
Menu	
 Home Home About this portal Latest updates	
Print Save Email	
Resource detail	

AS/NZS 1605:2000 Methods for sampling and analysing timber preservatives and preservative-treated timber

Table of Contents

<u>View on Information Provider website</u> {{ linkText }}

Abbreviation

AS/NZS 1605:2000

Valid from

Citations

11/05/2000

Information provider

Standards New Zealand

Author

Standards New Zealand, Standards Australia

Information type

New Zealand Standard

Format

PDF

Cited By

This resource is cited by 1 document (show Citations)

Description

This Standard sets out a series of methods for sampling and analysing timber preservatives and preservative-treated sawn and round timber.

Scope

Methods are grouped into five sections, i.e.

- sampling preservative liquids and preservative-treated timber,
- determination of preservative penetration,
- analysis of preservative retention,
- analysis of preservative solution concentration, and
- determination of presence of sapwood.

Appendices give examples of a test certificate and means for demonstrating compliance with this Standard.

 $\label{prop:control} \mbox{For assistance with locating previous versions, please contact the information provider.}$

This Standard is superseded by the AS/NZS 1605:2006 suite of Standards

For assistance with locating previous versions, please contact the information provider.

This Standard is superseded by the AS/NZS 1605:2006 suite of Standards

This resource is cited by:

AS/NZS 1605:2000 Methods for sampling and analysing timber preservatives and preservative-treated timber

This document is CITED BY:

• AS/NZS 1604.3:2002

AS/NZS 1605:2000 is cited by AS/NZS 1604.3:2002 Specification for preservative treatment - Plywood

Back

AS/NZS 1605:2000 Methods for sampling and analysing timber preservatives and preservative-treated timber

Show what documents this resource is CITED BY

Show what documents this resource CITES

Description

This Standard sets out a series of methods for sampling and analysing timber preservatives and preservative-treated sawn and round timber.

View on Information Provider website

AS/NZS 1605:2000 Methods for sampling and analysing timber preservatives and preservative-treated timber

Description

This Standard sets out a series of methods for sampling and analysing timber preservatives and preservative-treated sawn and round timber.

View on Information Provider website

This resource does not cite any other resources.

AS/NZS 1605:2000 Methods for sampling and analysing timber preservatives and preservative-treated timber

This resource does not CITE any other resources.



Section 1 Scope And General

- 1.1 Scope
- 1.2 Application
- 1.3 Referenced And Related Documents
- 1.4 Definitions
- 1.5 Report Of Test Results
- 1.6 Related Methods Of Analysis

Section 2 Sampling Preservative Liquids And Preservative-Treated Timber

- 2.1 General
- 2.2 Sampling Preservative Liquid
- 2.3 Method Of Sampling Preservative-Treated Timber
- 2.4 Preparation Of Test Specimens From The Sample

Section 3 Determination Of Preservative Penetration By Spot Tests

- 3.1 General
- 3.2 Preparation Of Test Pieces From Test Specimen
- 3.3 Recognition Of Penetration
- 3.4 Evaluation Of Penetration
- 3.5 Determination Of Pentachlorophenol Penetration In Timber Treated With Oil Solution
- 3.6 Determination Of Copper Penetration In Timber Treated With Copper-Based Preservatives-Method 1
- 3.7 Determination Of Copper Penetration In Timber Treated With Copper-Based Preservatives-Method 2
- 3.8 Determination Of Boron Penetration In Timber Treated With Boron-Based Preservatives
- 3.9 Determination Of Fluoride Penetration In Timber Treated With Fluoride-Based Preservatives

3.10 Determination Of Tin Penetration In Timber Treated With Tin-Containing Preservatives

Section 4 Analysis Methods For Determination Of Preservative Retention

- 4.1 General
- 4.2 Preparation Of Test Pieces From Test Specimen
- 4.3 Determination Of Copper, Chromium And Arsenic In Preservative-Treated Timber
- 4.4 Determination Of Boron In Preservative-Treated Timber
- 4.5 Determination Of Fluoride In Preservative-Treated Timber
- 4.6 Determination Of Pentachlorophenol (PCP) In Preservative-Treated Timber
- 4.7 Determination Of Creosote Or Pigment-Emulsified Creosote In Preservative-Treated Timber
- 4.8 Determination Of Tri-(N-Butyl) Tin Oxide In Preservative-Treated Timber
- 4.9 Determination Of Organochlorine Insecticides In Preservative-Treated Timber
- 4.10 Determination Of Copper In Copper Naphthenate In Preservative-Treated Timber
- 4.11 Determination Of Tin In Tri-(N-Butyl) Tin Oxide (TBTO) In Preservative-Treated Timber
- 4.12 Determination Of Tin In Tri-(N-Butyl) Tin Naphthenate (TBTN) In Preservative-Treated Timber
- 4.13 Determination Of Copper In ACQ (Ammoniacal Copper Quaternary) In Preservative-Treated Timber

Section 5 Analysis Methods For Determination Of Preservative Solution Concentration

- 5.1 General
- 5.2 Preparation Of Preservative Liquids And Solutions For Analysis
- 5.3 Determination Of Copper, Hexavalent Chromium, And Arsenic In CCa Preservative Solutions

- 5.4 Determination Of Boron In Preservative Solution
- 5.5 Determination Of Fluoride In Preservative Solution By Ion-Selective Electrode
- 5.6 Determination Of Pentachlorophenol In Preservative Solutions
- 5.7 Determination Of Tri-(N-Butyl) Tin Oxide (TBTO) In Preservative Treatment Solutions
- 5.8 Determination Of Organochlorine Insecticides In Preservative Treatment Solutions
- 5.9 Determination Of Tin In Tri-(N-Butyl) Tin Oxide (TBTO) Preservative Solutions By Atomic Absorption Spectrophotometry
- 5.10 Determination Of Tin In Tri-(N-Butyl) Tin Naphthenate (TBTN) Preservative Solutions By Atomic Absorption Spectrophotometry
- 5.11 Determination Of Ammonia In ACQ Preservative Solutions
- 5.12 Determination Of Copper In ACQ Preservative Solutions
- 5.13 Determination Of Water Content In High Temperature Creosote
- 5.14 Determination Of Matter Insoluble In Toluene For High Temperature Creosote
- 5.15 Determination Of Relative Density Of High Temperature Creosote
- 5.16 Test Of Distillation For High Temperature Creosote
- 5.17 Determination Of Coke Residue In High Temperature Creosote
- 5.18 Determination Of Phenols (Tar Acids) In High Temperature Creosote
- 5.19 Determination Of Closed Flashpoint Of High Temperature Creosote (Closed Cup)
- 5.20 Determination Of Limpid Point Of High Temperature Creosote Section 6 Determination Of Presence Of Sapwood
- 6.1 General
- 6.2 Determination Of Presence Of Sapwood In Coniferous Timber
- 6.3 Determination Of Presence Of Sapwood In Some Eucalypt Timbers

Appendix A - Examples Of A Test Certificate

Appendix B - Means For Demonstrating Compliance With This Standard

Print Save Email			
Feedback			
	_	_	
Contact usPrivacy policyDisclaimerCopyright			
		_	
<u>Feedback</u>			